

4.2 Frequency of the Tests

Mercury lamp and standard lamp tests should be performed at least once per month, on a schedule appropriate to the observing program data calculations and reporting. Ordinarily, it is sufficient to perform only one set of tests; however, if the test data should indicate that some change has occurred in the spectral characteristics of the instrument, it may be necessary to repeat one or more of the tests after certain corrective measures, to be described later, have been taken.

Comment: The wedge Calibration mentioned is not the wedge calibration performed with a two lamp unit.

Deleted: , preferably near the 28th day of the month, while wedge calibration tests should be performed at 3-month intervals

4.3 Recording of Test Data

Spectrophotometer test data may be recorded on a form similar to that shown in [Figure 2](#). The forms should be numbered consecutively in order to denote the order in which the tests are made. Any adjustments made to the spectrophotometer, or maintenance work performed, should be described on the back of the forms. With more modern computers, it is now possible to make worksheets that allow for the input of the information on this form, making the calculations directly as the data is input. Any organized method that allows the history of the tests and repairs to be easily reviewed is acceptable. It is very important that all records of the test data be saved in an organized manner, and studied for changes.

Deleted: should

OZONE SPECTROPHOTOMETER TESTS						STANDARDIZATION			
						Sterling, Va.			
						PLATE NUMBER			
						72			
Prepared in duplicate.						DATE			
YES						17 May 1962			
MERCURY LAMP TEST			STANDARD LAMP TEST			WEDGE CALIB. TEST			
Temp. {	Before	19.0°C	Lamp No.	72 Å		Wave length	Å Å D Å Å		
	End	14.0		Exst. Temp.	20.0°C		n With Rhodium Filter OUT	153.8	
	Mean	16.5			Room Temp.			21.0	
Q ₁ {	(1)	81.2	λ λ λ {	n		34.3	PLATE NO. ONLY	n With Rhodium Filter OUT	153.5
	(2)	88.1		n	34.3	n With Rhodium Filter IN		10.6	
	Mean	84.7		n	34.3	n		90.6	
Q ₂ {	(1)	80.2	c λ λ {	n	35.7	Mean { out	153.6		
	(2)	88.1		n	35.6		n { in	90.6	
	Mean	84.15		n	35.6		Mean { out	122.2	
Q ₃ {	(1)	86.2	c' λ λ {	n	77.7	n { in	48.7		
	(2)	85.0		n	77.7		Δ N	58.5	
	Mean	84.6		n	79.8		n With Rhodium Filter OUT	92.8	
Q ₄ {	(1)	81.2	c λ λ {	n	36.2	n With Rhodium Filter OUT	92.9		
	(2)	88.1		n	36.1		92.8		
	Mean	84.45		n	36.1		n With Rhodium Filter IN	29.0	
Q ₅ {	(1)	81.2	Mean A	34.3		Mean { out	92.8		
	(2)	88.1		Values C	35.6		n { in	29.0	
	Mean	84.65			nF C		77.7		Mean { out
Q ₁ Mean of Above		84.65	n	36.1		n { in	29.0		
Q ₁ from Table		84.50		Time With at .02 Voltage	2.4"		Mean { out	70.9	
Difference		+0.15				n { in	12.5		
						Δ N			
Signature						58.4			
102									

Figure 2. Sample form for recording spectrophotometer tests data.